Digitrax Function Remapping

The CV values that are permitted for function remapping are limited to 8 bits, a maximum value of 255. Therefore only 8 functions can be mapped to each function key. Digitrax uses CV33-CV46 to handle remapping according to published standards.

_			Function Lead Color (Number)											
Throttle Function Key	Map CV	Factory Setting DEC/HEX	Wht 0	Yel 0	Grn 1	Vio 2	Brn 3	Wht/ Yel 4	Wht Grn 5	Wht/ Blu 6	9	10	11	12
F0F	CV33	001/x001	1	2	4	8	16	32	64	128				
F0R	CV34	002/x002	1	2	4	8	16	32	64	128				
F1	CV35	004/x004	1	2	4	8	16	32	64	128				
F2	CV36	800x/800	1	2	4	8	16	32	64	128				
F3	CV37	016/x10	1	2	4	8	16	32	64	128				
F4	CV38	004/x004				1	2	4	8	16	32	64	128	
F5	CV39	800x/800				1	2	4	8	16	32	64	128	
F6	CV40	016/x10				1	2	4	8	16	32	64	128	
F7	CV41	032/x20				1	2	4	8	16	32	64	128	
F8	CV42	064/x40	values not assignable for			1	2	4	8	16	32	64	128	
F9	CV43	016/x10	leads in these columns						1	2	4	8	16	32
F10	CV44	032/x20							1	2	4	8	16	32
F11	CV45	064/x40							1	2	4	8	16	32
F12	CV46	128/x80							1	2	4	8	16	32

Function remapping is easy! Just follow these simple steps

- 1. Locate the row for the Throttle Function Key that you want to use.
- 2. Locate the column of the Function Lead Color (number) you want to control.
- 3. Note the value at the intersection of the row and column.
- 4. Program that value into the the CV listed next to the Throttle Function Key.

Example 1. Single Function Remapping

You want to Control a whistle with the Throttle Function F2 key which will blow the whistle for as long as you hold the key down. The sound board that creates the whistle is wired to the Brown lead (function output 3).

- 1. Locate the row for the Throttle Function Key F2 you want to use.
- 2. Locate the column of the Function Lead Color (function output number) you want to control, Brown (3).
- 3. Note the value, 16, at the intersection of the row and column (Yellow box with red outline in chart).
- 4. Enter this value, 16, into the the CV listed next to the Throttle Function Key, CV36.
- 5. The Throttle Function Key will now control the item connected to the Brown function lead.

Example 2. Multiple Function Remapping

You want to control two lights with a single Throttle Function Key. The lights are cab lights and running lights that only come on at night. One light is wired to the Brown (3) lead and one is wired to the White/Yellow (4) lead. You want to use Throttle Function Key 8 to control these lights.

- 1. Find row for Throttle Function Key F8 and follow it across to the column for the Brown lead and note the value, 2. Continue to the White Yellow column and note the value, 4.(Greeen boxes in chart)
- 2. Since you want both function leads to work at the same time, add the two values together, 2+4=6.
- 3. Enter this value, 6, into the the CV listed next to the Throttle Function Key F8, CV42.
- The functions connected to Brown and the White/Yellow leads will now turn on and off with Throttle Function Key 2.